


## Cancer Prediction Results

Please select classification criteria:




# Early Cancer Detection using Data Science Tools

Peter Liu

Dallas AI

2018.7.26

# About me



**Dr. Peter LIU**  
**Energy Industry**


**Ph.D., Colorado State University**  
**Scientist, Sandia National Labs**

## Green Chemistry

Cutting-edge research for a greener sustainable future

www.rsc.org/greenchem

Volume 14 | Number 10 | October 2012 | Pages 2649-2652



RSC Publishing

**COVER ARTICLE**  
Chen et al.  
Organocatalytic upgrading of the long fossil-fueled building block for a catalyst  
into liquid and biodegradable polymers

(12) **United States Patent**  
**Chen et al.**

(54) **BIOREFINING COMPOUNDS AND  
ORGANOCATALYTIC UPGRADING  
METHODS**

(71) Applicant: **COLORADO STATE UNIVERSITY  
RESEARCH FOUNDATION**, Fort  
Collins, CO (US)

(72) Inventors: **Eugene Y. Chen**, Fort Collins, CO  
(US); **Dajiang Liu**, Fort Collins, CO  
(US)

(73) Assignee: **Colorado State University Research  
Foundation**, Fort Collins, CO (US)

*2015 Presidential Green Chemistry  
Challenge Award*

*is presented to*

**Dajiang (DJ) Liu**

*of*

**Colorado State University**

*for*

**Greener Condensation Reactions for Renewable Chemicals,  
Liquid Fuels, and Biodegradable Polymers**



*Gina McCarthy*  
Administrator

# Sections

- **Early cancer detection**

*“How Data Science Enables Early Cancer Diagnosis”* on Medium

- ML application to ‘red-flag’ suspected cancer patients

- **Machine learning product development**


- App development using Dash

- **Other interesting topic**

*“Scan-and-Bingo Approach for Product Authentication”* on Medium

- ML application to authenticate our food products


# My Pet Hamster Passed Away Due to Cancer




# Top 3 Cancers in United States

## Five Years' Survival Rates at Different Stages


### Breast Cancer



### Lung Cancer




### Prostate Cancer



**Early Detection/Treatment = Higher Survival Rate**

# Typical Procedures for Cancer Diagnosis



## Problems:


- Some cancer does not have symptoms until late stage
- Difficult to link symptoms with cancer

# Early Detection of Cancer

## Goal

- “Red Flag” the suspected cancer samples using routine checkup samples(*e.g.*, blood, serum)
- App development to aid cancer screening

# Who Cares?





# Approach

- **Shotgun Method**

Analyze routine check up samples, *e.g.* blood samples, and **collect as much information as possible** for cancer detection

- **Red Flag Suspects**


Identify samples that have high probability of cancer and recommend for further testing

# Shotgun Method

- **Mass Spectrometry**
  - Collect mass information of all chemicals
- **Low Sample Loading**
  - Milligram (1/1000 grams) samples
- **High Sensitivity**
  - Detect trace amount of chemicals at parts per billion(ppb) level
- **High Throughput Screening**
  - Easily coupled with robotic sample preparation process and results obtained within minutes

# Problems with Shotgun Method

- Difficult to compare unless you already know which peak is the determinant



# Real-world Problem to ML Problem

## Real-world Problem

1. Select Determinant Masses
2. Predict Cancer



## Machine Learning Problem

1. Feature Selection
2. Classification

## Determinant Masses Selection vs. Important Features Selection

Cancer/No Cancer


VS.

1/-1

M/Z	200.17821	200.44238	200.70672	200.97123	201.23592	201.50078	201.76582	202.03103	202.29642	202.56198	...	9982.7063	9984.5
0	1.720546	1.720546	1.720546	1.719901	1.717815	1.713023	1.692505	1.672132	1.636220	1.560843	...	0.0	0.0
1	1.524127	1.501587	1.463949	1.407535	1.325125	1.226132	1.120034	1.005362	0.893435	0.777613	...	0.0	0.0
2	1.637911	1.637911	1.631477	1.612273	1.581629	1.525683	1.435933	1.330684	1.193543	0.997459	...	0.0	0.0
3	1.656036	1.656036	1.656036	1.651223	1.634340	1.590969	1.525195	1.444791	1.340823	1.217818	...	0.0	0.0
4	1.793301	1.793301	1.793301	1.793301	1.791395	1.785510	1.767697	1.722631	1.655785	1.542241	...	0.0	0.0

# Data Source

- Sample mass spectra collected from National Cancer Institute (NCI)
- **Two cancers**
- **Three groups**
- **Six subgroups**



# Data Wrangling

“Long” single MS data

M/Z	Intensity
#####	4.100553
2.18E-07	4.120664
9.60E-05	4.036199
0.000366	4.124686
0.00081	4.026144
0.001429	3.945701
0.002221	3.879336
0.003188	3.985923
0.004329	4.016089
0.005644	4.004022
0.007133	4.070387
0.008797	3.981901

Mass cutoff

Scaling

Transpose



“Wide” single MS data

Mass values

M/Z	200.17821	200.44238	200.70672	200.97123	201.23592	201.50078	201.76582	202.03103	202.29642	202.56198	...	9982.7063	9984.5713	9986.4363
0	1.720546	1.720546	1.720546	1.719901	1.717815	1.713023	1.692505	1.672132	1.636220	1.560843	...	0.0	0.0	0.0

Concatenation by Row



Mass Spectra Data Matrix

Mass values


M/Z	200.17821	200.44238	200.70672	200.97123	201.23592	201.50078	201.76582	202.03103	202.29642	202.56198	...	9982.7063	9984.5713	9986.4363
0	1.720546	1.720546	1.720546	1.719901	1.717815	1.713023	1.692505	1.672132	1.636220	1.560843	...	0.0	0.0	0.0
1	1.524127	1.501587	1.463949	1.407535	1.325125	1.226132	1.120034	1.005362	0.893435	0.777613	...	0.0	0.0	0.0
2	1.637911	1.637911	1.631477	1.612273	1.581629	1.525683	1.435933	1.330684	1.193543	0.997459	...	0.0	0.0	0.0
3	1.656036	1.656036	1.656036	1.651223	1.634340	1.590969	1.525195	1.444791	1.340823	1.217818	...	0.0	0.0	0.0
4	1.793301	1.793301	1.793301	1.793301	1.791395	1.785510	1.767697	1.722631	1.655785	1.542241	...	0.0	0.0	0.0

Samples

# Exploratory Data Analysis


**Heatmap is more preferable than plot view**

Plot view of data



1D Heatmap


typical ovarian cancer sample



# Exploratory Data Analysis

## Heatmap of robotic prepared ovarian datasets

- Difficult to tell the difference between cancer and control group






# Exploratory Data Analysis

## Heatmap of hand prepared ovarian datasets


- Difficult to tell the difference between cancer and control group



# Exploratory Data Analysis

## Heatmap of hand prepared prostate samples

- Difficult to tell the difference between cancer and control group



# Data Visualization based on PCA

**Easy to tell the difference!**




Figure. Comparison of cancer and non-cancer group in three datasets. **Purple** plots represent **non-cancer** group, while **yellow** plots represent **cancer** group

# Feature Selection by Random Forest

**Important Features = Fingerprint Mass**

**Less than 1% features were needed**




Figure. Explained Variance vs. Number of Features rendered by **Random Forest**. Decision Tree is a natural way of feature selection

# Feature Selection

## Feature Selection is not only for Modeling!

- Fingerprint masses inspire drug development
- One key molecule (molecular weight 472) to determine ovarian cancer is in our list of fingerprint masses




Figure. Selected fingerprint masses for robotic prepared ovarian samples

### Reference

<https://academic.oup.com/ajcp/article/134/6/903/1760577>

# Models for Cancer Prediction

**Table 1. Comparison of different models on cancer prediction**

Datasets	Measure	Models after tuning parameters			
		KNN	Random Forest	SVM	Ensemble by Voting
Ovarian Robotic	Accuracy	0.99	1.00	1.00	0.99
	AUC	0.99	1.00	1.00	0.99
	F1-Score	0.99	1.00	1.00	0.99
Ovarian Hand	Accuracy	0.93	0.92	0.95	0.92
	AUC	0.93	0.91	0.94	0.92
	F1-Score	0.94	0.93	0.96	0.93
Prostate	Accuracy	0.95	0.98	0.98	0.98
	AUC	0.95	0.97	0.97	0.98
	F1-Score	0.96	0.98	0.98	0.98

# FP and FN

**Which model is better in early detection of cancer?**

- Lower false negatives

**Model 1**

Predicted Actual	-1 (No Cancer)	1 (Cancer)	Total
-1 (No Cancer)	23	3 (FP)	26
1 (Cancer)	0 (FN)	34	34
Total	23	37	60

**Model 2**

Predicted Actual	-1 (No Cancer)	1 (Cancer)	Total
-1 (No Cancer)	23	0 (FP)	26
1 (Cancer)	3 (FN)	34	34
Total	23	37	60

# SVM vs. Ensemble

## SVM

Robotic prepared Ovarian Samples	Hand prepared Ovarian Samples	Prostate Samples
Confusion Matrix: Predicted   -1   1   __all__ Actual -1            27   0            27 1            0   49            49 --all--    27   49            76	Confusion Matrix: Predicted   -1   1   __all__ Actual -1            23   3            26 1            0   34            34 --all--    23   37            60	Confusion Matrix: Predicted   -1   1   __all__ Actual -1            16   1            17 1            0   23            23 --all--    16   24            40

## Ensemble

Predicted   -1   1   __all__ Actual -1            27   0            27 1            1   48            49 --all--    28   48            76	Predicted   -1   1   __all__ Actual -1            22   1            23 1            4   33            37 --all--    26   34            60	Predicted   -1   1   __all__ Actual -1            16   0            16 1            1   23            24 --all--    17   23            40
---	---	---

- SVM is our best model
- 0% of FN rate (fail to detect cancer) by SVM



# Product Development

## Cancer Diagnosis 1.0

- **Web App** developed based on Dash
- Simply **upload spectrum file** and cancer diagnosis results will be shown

### Upload file

Welcome to Cancer Diagnosis 1.0

---

- ▶ About
  - ▶ Instructions
- 

Please upload mass spectrum file:



Upload mass spectrum csv/excel from your own computer

UPLOAD FILE

Please select sample group. If unknown, select 'Unknown'

Unknown Samples

# Mass Spectrum Preview

- Mass spectrum will be shown using heatmap and plot, and you can choose the mass range


## Sample Mass Spectrum

Please select mass range to show mass spectrum:




You have selected mass range from 200 to 6032

Spectrum Shown by Heatmap



Spectrum Shown by Plot

Compare data on hover



# Classification of Unknown Sample

- It shows the visualization of new sample within training samples and predict the probability by four models. You can choose different classification criteria: all, sex or preparation


## Cancer Prediction Results

Please select classification criteria:


All



Sample Projection using First Two Principal Components



Predicted Probability by Four Models



# Prediction of Cancer/No Cancer in Specific Group

- If you choose specific group (Robotic prepared ovarian group herein), it shows the visualization of new sample within training samples in this group, and predict the probability of cancer/no cancer by four models


## Cancer Prediction Results

Please select classification criteria:


Cancer/No Cancer



Sample Projection in Robotic Prepared Ovarian Group



Predicted Probability by Four Models



# Fingerprint Masses in Specific Group

- It will also show the fingerprint masses within specific group (robotic prepared ovarian group herein), you can select the mass range to show interested fingerprint masses

## Fingerprint Masses for Cancer Diagnosis


Please select mass range:



You have selected mass range from 200 to 1000

The number of fingerprint masses between 200 and 1000 are: 25

The fingerprint masses are: [245, 247, 295, 321, 434, 435, 435, 436, 440, 472, 508, 554, 555, 620, 628, 628, 632, 634, 652, 669, 691, 831, 833, 967]



# Conclusion

- SVM were selected as the best model to predict ovarian and prostate cancers with high accuracy (95-100%), and 0% false negative rate, making it ideal to “red flag” the suspected cancer samples
- One of the fingerprint molecules determining ovarian cancer was identified, which is confirmed by literature report
- A cancer diagnosis app was developed to offer quick cancer prediction results as well as lists of fingerprint molecules for cancer diagnosis

# Recommendations

- **Patients** should ask for mass spectrum test during routine check up for cancer screening
- **Doctors** should recommend patients to do mass spectrum test during routine check up
- **Insurance company** should cover the mass spectrum test fee as preventative test to encourage people do routine cancer screening

# Goal of Early Cancer Detection

- ✓ “Red Flag” the suspected cancer samples using routine checkup samples(*e.g.*, blood, serum)
- ✓ App development to aid cancer screening
- ✗ Increase the number of training/testing samples
- ✗ Add more cancers

## Look into the future

**Cancer diagnosis as easy as blood sugar test!**



# Product Authentication

“*Scan-and-Bingo Approach for Product Authentication*” on Medium

- ML application to authentic your food and cosmetic products

## Goal

- Develop a more reliable and efficient way to “**Red Flag**” those suspected counterfeits in the first place, e.g., cosmetic products, food, fuels

All data are publicly available through [Quadram Institute](#)

# Approach



- **Shotgun Method**

Scan sample using hand-held FTIR, and **collect chemical information**

- **“Red Flag” Suspects**

Identify whether the product is counterfeit

# Fourier Transform Infrared Spectrometry (FTIR)




# Authentic Or Not?




# Strawberry Jam FTIR

- Total 983 samples: 351 authentic strawberry samples, 632 non-strawberry samples

Comparison of Strawberry and Non-strawberry samples



# Spectra Projection based on PCA



# Model Performance

## Supported Vector Classifier

```
report('svc', ytest, svc_predict)
```

```
Report of svc
```

```
=====
```

```
Accuracy of the model:0.976271186440678
```

```
AUC score:          0.9725453135601435
```

```
F1 score:           0.9688888888888889
```

```
Confusion Matrix:
```

```
[[179   2]
```

```
 [  5 109]]
```

---

## Logistic Regression (**Problematic!**)

```
report('logistic', ytest, logistic_predict)
```

```
Report of logistic
```

```
=====
```

```
Accuracy of the model:0.6135593220338983
```

```
AUC score:          0.5
```

```
F1 score:           0.0
```

```
Confusion Matrix:
```


```
[[181   0]
```

```
 [114   0]]
```

# Fresh Meat FTIR


- 120 meat samples: 40 chicken samples, 40 pork samples and 40 turkey samples

Comparison of Meat samples between Chicken, Pork and Turkey





# Spectra Projection based on PCA



# Model Performance

## Supported Vector Classifier (SVC)

```
report('svc', ytest, svc_predict)
```

Report of svc

=====

Accuracy of the model:1.0

Confusion Matrix:

```
[[11  0  0]
 [ 0  9  0]
 [ 0  0 16]]
```

## Linear Discriminant Analysis (LDA)

```
report('LDA', ytest, lda_predict)
```

Report of LDA

=====

Accuracy of the model:1.0


Confusion Matrix:

```
[[11  0  0]
 [ 0  9  0]
 [ 0  0 16]]
```


# Origin of Olive Oil

- 120 olive oil samples: 20 from Greece, 34 from Italy, 16 from Portugal and 50 from Spain

Comparison of Olive Oils from Greece, Italy, Portugal and Spain



# Spectra Projection based on PCA



# Model Performance

## Supported Vector Classifier (SVC)

```
# Use first 12 principal components for prediction
xtrain, xtest, ytrain, ytest = train_test_split(xdata_transform[:, :12], ydata, test_size = 0.3, random_state = 3)
pipeline = make_pipeline(StandardScaler(), SVC())
param = {'svc__gamma': 10.0**np.arange(-3,3), 'svc__C': 10.0**np.arange(-3,3)}
gs_svc = GridSearchCV(pipeline, param_grid=param)
gs_svc.fit(xtrain, ytrain)
svc_predict = gs_svc.predict(xtest)
report('SVC', ytest, svc_predict)
```

Report of SVC

```
=====
Accuracy of the model:1.0
Confusion Matrix:
[[ 8  0  0  0]
 [ 0  7  0  0]
 [ 0  0  2  0]
 [ 0  0  0 19]]
```

# Conclusion

- A **scan-and-bingo approach** was proposed **as proof of authentication**: Scan sample by hand-held FTIR and analyze by machine learning tools
- A satisfactory **high accuracy** (>98%) was achieved, and this method also offered us with deep understandings on the key difference between samples.
- This toolkit is especially interesting for **product distributors**, such as Walmart, Target, and Wholefoods, for quick assessment of product quality, as well as **product manufacturer** for quick assessment of quality

**Thank you!**

**Stay cool!**